

ECDIS 模拟器教练员站操作规程

一、开机

- 1、接通总电源、教练员站和学生端的电源；
- 2、手动开启投影仪、功放和麦克风；
- 3、手动开启教练员站计算机；
- 4、运行教练员站软件 MTI-Server 和远程控制管理软件 MTI-Control；
- 5、在 MTI-Control 中远程启动所有或根据需要确定的学生端计算机，然后远程运行所开启学生端的所有软件终端；
- 6、在 MTI-Server 系统中根据教学规模与要求编辑练习并保存（详见使用指南）；
- 7、各学生端正常登录后，在 MTI-Server 中分配练习给各学生端；
- 8、初始化各学生端，然后点击“运行”，即可进入教学和训练。

二、关机

- 1、激活教练员站软件 MTI-Server，停止所有练习，并按提示保存记录后，退出 MTI-Server；
- 2、激活远程控制管理软件 MTI-Control，点击关闭学生端的所有软件终端，然后关闭所有学生端计算机；
- 3、待所有学生端计算机关闭后，退出 MTI-Control，关闭教练员站计算机；
- 4、关闭投影仪、功放和麦克风；
- 5、切断教练员站、学生端的电源和总电源。

三、注意事项

- 1、严禁在模拟器上使用外来的软盘、光盘和 U 盘；
- 2、严禁学员或教员在实验室内的电脑上使用 U 盘等安装、拷贝、使用其他软件。

ECDIS simulator coach station operating instruction

1 Power On

- 1.1 Switch on the power supply of the coach station, student terminal and the main;
- 1.2 Manually start the projector, amplifier and microphone;
- 1.3 Manually start the coach station PC;
- 1.4 Run the coach station software MTI-Server and remote control software MTI-Control;
- 1.5 Start all or the specific student terminal's PCs in the MTI-Control, then start all the software terminals within the students' terminals remotely;
- 1.6 Edit and save the exercises according to the requirement and scale of the teaching and training (see details in the guide) within the MTI-Server;
- 1.7 After the student terminals logging in normally, allocated the exercises to all the student terminals in MTI-Server;
- 1.8 Initializing all the student terminal, then press Run, the training work can be executed.

2 Power Off

- 2.1 Activate the coach station software MTI-Server, stop all the practice and save the record by the notice, and quit MTI-Server;
- 2.2 Activate the remote control software MTI-Control, close all the software and all the PCs of the students;
- 2.3 When all the PCs are powered off, quit MTI-Control and close the PC of the coach station;
- 2.4 Close projector, amplifier and microphone;
- 2.5 Cut off the power supply of the coach, students' terminal and the main.

3 Cautions

- 3.1 The external soft disk, CD and U disk are prohibited using in the system;
- 3.2 The coach and the trainees are not allowed to install copy and use other software with U disk in the system.